




KIDS

	R / SIZE	B	C	D	E	F	G	H	I	J	K	L
WILD SPEED 26	34cm  152	340	530	73°	70°	90	430	1017	532	368	698	40
WILD SPEED 24	31cm  128	310	500	72°	70°	90	410	958	508	335	663	35
WILD CROSS 24 + 24 STREET	31cm  128	310	500	72°	70°	120	410	953	495	339	650	45
WILD SPEED 20	27cm  116	270	430	72°	68.5°	80	350	837	432	289	545	35
WILD CROSS 20	27cm  116	270	430	72°	69°	100	350	830	421	293	533	40
WILD CROSS 16	23cm  104	230	400	69°	68°	100	317	723	399	239	410	30
WILD CROSS 12	18cm  92	180	340	69°	68°	100	266	629	322	213	338	+10
WILD BUDDY 12	12cm  86	160	350	71°	68°	100	220	572	-	-	271	40
WILD BUDDY 10	12cm  86	120	330	69°	72°	90	200	535	-	-	235	30
WILD ONE 24	31cm  128	310	484	72.5°	70°	100	420	954	509	324	633	50
WILD ONE 20	29cm  116	290	410	73°	71°	100	365	829	437	277	573	15
WILDCAT 24	35cm  128	350	522	73°	71°	120	400	979	487	374	412	25
WILDCAT 20	30,5cm  116	305	442	73°	71°	100	360	860	409	317	356	15
COUNTRY STAR E	37cm / XS	370	555	71,5°	70°	137	435	1035	574	363	444	35
	43cm / S	430	574	71,5°	70°	160	435	1054	596	375	446	35
	51cm / L	510	587	71,5°	70°	160	435	1068	594	388	461	35
COUNTRY STAR LADY	37cm / XS	370	541	72°	71°	125	430	1009	564	358	635	35
	42cm / S	420	561	72°	71°	137	430	1029	576	374	648	35
	47cm / M	470	578	72°	71°	155	430	1046	593	385	649	35